Connected Essentials CEU10 User Guide

1. Introduction

This mains socket adaptor is designed to fit into standard British 13A wall socket and includes two USB charging points with a maximum output of 1 amp, and 1 standard 13A socket. The USB Charger is only operational when a compatible charging lead is inserted. The charging circuit is designed to ensure no current draw without insertion of a USB plug.

Technical Information:

- Working voltage : 13A, 250V
- USB output : 1 amp, 5 volt
- Dimensions - 120 x 80 x 60mm.
- Fits a standard UK mains socket

Warning:
Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the users authority to operate the equipment. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Further information can be found at www.connectedessentials.co.uk.

WEEE Directive
Directive 2002/96/EC OF THE EUROPEAN PARLIAMENT AND COUNCIL OF 27th January 2003 on waste electrical equipment. Products that include the WEEE symbol shown below should not be placed in the normal household waste, but should be disposed of using the appropriate WEEE disposal facility. Those facilities may be advised to you by your local council or organisation from which the product(s) was purchased. For the latest information on the WEEE directive please access the following website www.environment-agency.gov.uk/weee.

Important Information:
1. Please note - All the safety and operating instructions should be read before the appliance is operated.
2. Retain Instructions - The safety and operating instructions should be retained for future reference.
3. Heed Warnings - All warning on the appliance and in the operating instructions should be adhered to.
4. Follow Instructions - All operating and usage instructions should be followed.
5. Water and Moisture - The appliance should not be used near water, for example, near a bathtub, washbowl, kitchen sink, washing machine, in a wet basement or near a swimming pool.
6. Power Sources - The appliance should be powered only as described in these operating instructions or as marked on the appliance.
7. Do not leave the unit unattended while in use.
8. This electric product is not a toy! To avoid risk of fire, burns, personal injury and electric shock keep out of reach of children.
9. Do not use this product for other than its intended use.
11. Electrical ratings of the extension cord must be as high as, or higher than the electrical ratings of the product.
12. Do not cover the product with cloth, paper or any material that is not part of the product when it is in use.
13. **CAUTION**: to reduce the risk of fire do not deliberately reposition pins on the plug assembly.
14. **WARNING:** Keep unit and power cord out of reach of children.
15. **ALWAYS**: switch off at the mains socket when not in use.
16. No repair should be carried out by the user

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
WARNING: TO PREVENT THE RISK OF FIRE OR ELECTRIC SHOCK,DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.
TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.
:This lighting flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be a sufficient magnitude to constitute a risk of electric shock to persons.
:This exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.